

**CONDUCTIVITY METERING SYSTEM
Model SC8SG
CONDUCTIVITY DETECTOR**

IM 12D08G02-01E

◆ Introduction

Conductivity Measuring System consists of a SC8SG Conductivity Detector, as described in this manual, used in conjunction with a SC202, FLXA202/FLXA21 or FLXA402, SC402G, SC450G Conductivity Converter.

The SC8SG Conductivity Detector may use sensors with cell constant of 0.01 cm^{-1} to measure conductivities of 0 to $100 \mu\text{S/cm}$, sensors with cell constant of 0.1 cm^{-1} to measure conductivities of 0 to 10 mS/cm , or sensors with cell constant of 10 cm^{-1} to measure conductivities of 0 to 1000 mS/cm .

The sensors with cell constants of 10 cm^{-1} may be two-electrode or four-electrode types: four-electrode types have the advantage that they are much less likely to be affected by polarization-related errors. They can be more consistent and accurate both with solutions with high impurities or liquids of high conductivities.

The SC8SG detector may be inserted into the process piping for direct measurement of process liquids, or a sample of the liquid may be obtained via a piping connection.

This user manual is intended to cover installation, piping and wiring, periodic inspection and maintenance for the SC8SG Conductivity Detector.

This manual does not describe the units in the table below which are the component units of the conductivity measuring system. Each of these units comes with an instruction manual. Read the applicable manuals for details of the units concerned.

Model	User's manual	Manual number
FLXA202, FLXA21	2-Wire Liquid Analyzer	IM 12A01A02-01E
FLXA402	4-Wire Converter	IM 12A01F01-02EN IM 12A01F03-01EN etc.
SC402G	Conductivity and Resistivity Converter	IM 12D08N04-01E
SC450G	Conductivity and Resistivity Converter	IM 12D08N05-01E
SC202G SC202SJ	2-Wire Conductivity Transmitter	IM 12D08B02-01E
SA11	SA11 Smart Adapter	IM 12A06S01-00EN-P

Upon delivery, unpack the instrument carefully and inspect it to ensure that it was not damaged during shipment. If damage is found, retain the original packing materials (including the outer box) and notify immediately the carrier and the relevant YOKOGAWA sales office.

Make sure the model code on the label agrees with your order. For the meaning of the model code, refer to the Model and Suffix code table. (See subsection 1.2.2)

◆ For the safe use of this equipment

■ Safety, Protection, and Modification of the Product

- In order to protect the system controlled by the product and the product itself and ensure safe operation, observe the safety precautions described in this user's manual. We assume no liability for safety if users fail to observe these instructions when operating the product.
- If this instrument is used in a manner not specified in this user's manual, the protection provided by this instrument may be impaired.
- Be sure to use the spare parts approved by Yokogawa Electric Corporation (hereafter simply referred to as YOKOGAWA) when replacing parts or consumables.
- Modification of the product is strictly prohibited.
- The following symbols are used in the product and user's manual to indicate that there are precautions for safety:



WARNING

This symbol indicates that an operator must follow the instructions laid out in this manual in order to avoid the risks, for the human body, of injury, electric shock, or fatalities. The manual describes what special care the operator must take to avoid such risks.



CAUTION

This symbol indicates that the operator must refer to the instructions in this manual in order to prevent the instrument (hardware) or software from being damaged, or a system failure from occurring.

The following are signal words to be found only in our instruction manuals.

CAUTION

This symbol gives information essential for understanding the operations and functions.

NOTE

This symbol indicates information that complements the present topic.

■ Warning and Disclaimer

The product is provided on an "as is" basis. YOKOGAWA shall have neither liability nor responsibility to any person or entity with respect to any direct or indirect loss or damage arising from using the product or any defect of the product that YOKOGAWA can not predict in advance.

■ Notes on Handling User's Manuals

- Please hand over the user's manuals to your end users so that they can keep the user's manuals on hand for convenient reference.
- Please read the information thoroughly before using the product.
- The purpose of these user's manuals is not to warrant that the product is well suited to any particular purpose but rather to describe the functional details of the product.
- No part of the user's manuals may be transferred or reproduced without prior written consent from YOKOGAWA.
- YOKOGAWA reserves the right to make improvements in the user's manuals and product at any time, without notice or obligation.
- If you have any questions, or you find mistakes or omissions in the user's manuals, please contact our sales representative or your local distributor.

■ Drawing Conventions

Some drawings may be partially emphasized, simplified, or omitted, for the convenience of description.

Some screen images depicted in the user's manual may have different display positions or character types (e.g., the upper / lower case). Also note that some of the images contained in this user's manual are display examples.

■ Product Disposal

The instrument should be disposed of in accordance with local and national legislation/regulations.

■ Trademark Acknowledgments

- All other company and product names mentioned in this user's manual are trademarks or registered trademarks of their respective companies.
- We do not use TM or ® mark to indicate those trademarks or registered trademarks in this user's manual

◆ After-sales Warranty

- **Do not modify the product.**

- **During the warranty period, for repair under warranty consult the local sales representative or service office. Yokogawa will replace or repair any damaged parts. Before consulting for repair under warranty, provide us with the model name and serial number and a description of the problem. Any diagrams or data explaining the problem would also be appreciated.**
 - If we replace the product with a new one, we won't provide you with a repair report.
 - Yokogawa warrants the product for the period stated in the pre-purchase quotation. Yokogawa shall conduct defined warranty service based on its standard. When the customer site is located outside of the service area, a fee for dispatching the maintenance engineer will be charged to the customer.

- **In the following cases, customer will be charged repair fee regardless of warranty period.**
 - Failure of components which are out of scope of warranty stated in instruction manual.
 - Failure caused by usage of software, hardware or auxiliary equipment, which Yokogawa Electric did not supply.
 - Failure due to improper or insufficient maintenance by user.
 - Failure due to modification, misuse or outside-of-specifications operation which Yokogawa does not authorize.
 - Failure due to power supply (voltage, frequency) being outside specifications or abnormal.
 - Failure caused by any usage out of scope of recommended usage.
 - Any damage from fire, earthquake, storms and floods, lightning, disturbances, riots, warfare, radiation and other natural changes.

- **Yokogawa does not warrant conformance with the specific application at the user site. Yokogawa will not bear direct/indirect responsibility for damage due to a specific application.**

- **Yokogawa Electric will not bear responsibility when the user configures the product into systems or resells the product.**

- **Maintenance service and supplying repair parts will be covered for five years after the production ends. For repair for this product, please contact the nearest sales office described in this instruction manual.**

CONDUCTIVITY METERING SYSTEM
Model SC8SG
CONDUCTIVITY DETECTOR

IM 12D08G02-01E 7th Edition

CONTENTS

- ◆ Introduction.....i
- ◆ For the safe use of this equipment.....ii
- ◆ After-sales Warrantyiv
- 1. General 1-1
 - 1.1 Features of SC8SG Conductivity Detector 1-1
 - 1.2 Specifications..... 1-2
 - 1.2.1 Standard Specifications 1-2
 - 1.2.2 Model and Suffix Codes..... 1-4
 - 1.2.3 Dimensions 1-6
- 2. Components and Their Function..... 2-1
- 3. Installation, Piping and Wiring..... 3-1
 - 3.1 Installation 3-1
 - 3.1.1 Preparation for Detector Installation 3-1
 - 3.1.2 Detector Installation 3-4
 - 3.2 Piping 3-5
 - 3.2.1 Piping Materials 3-5
 - 3.2.2 Making Sampling piping..... 3-5
 - 3.3 Wiring 3-8
 - 3.3.1 Detector Cable Specifications 3-8
 - 3.3.2 Laying Detector Cables 3-8
- 4. Operation..... 4-1
 - 4.1 Preparation for Operation 4-1
 - 4.1.1 Checking Piping and Wiring..... 4-1
 - 4.1.2 Flowing Measured solution 4-1
 - 4.1.3 Checking Operation 4-1
 - 4.2 Steady-State Operation 4-2
 - 4.2.1 If any problem arises during operation 4-2
 - 4.2.2 Cautions When Stopping or Resuming Operation 4-2
- 5. Inspection and Maintenance 5-1
 - 5.1 Cleaning the Detector 5-2
 - 5.1.1 Guidelines for Cleaning..... 5-2
 - 5.1.2 Removing the Detector 5-2
 - 5.1.3 Cleaning 5-3
 - 5.2 Inspection of O-ring Sealing 5-3

Customer Maintenance Parts List.....CMPL 12D08G02-01E

Revision Informationi

1. General

1.1 Features of SC8SG Conductivity Detector

- The SC8SG Conductivity Detector with cell constant of 0.01 cm⁻¹/ 0.1 cm⁻¹/ 10 cm⁻¹ enables the conductivity measurement ranging from 0.05 μS/cm to 1000 mS/cm in a variety of processes.
- High conductivity solutions can be measured stably for prolonged periods of time.

In high-conductivity solution measurements, polarization is likely to cause measurement errors. Two-electrode and four-electrode detectors with cell constants of 10 cm⁻¹ are available for measurement of high-conductivity solutions. Four-electrode detectors are less likely to be affected by polarization, enabling more stable measurements, and they can measure conductivity of solutions with high conductivities. Polarization may also be caused by contamination of electrodes. The four-electrode detector is less likely to be affected by polarization, and is less affected by dirty electrodes, so requires less maintenance.

- Direct mounting on the process piping also allows the detector to measure the conductivity of high-temperature solutions.

We offer both Flow-through (sampling) type and Screw-in type SC8SG Conductivity Detectors. They can measure solutions with temperatures up to 130°C such as hot bliler water with a cell constant of 0.01 cm⁻¹.

Pt 1000 sensor in the detector provides precise temperature measurement for reference temperature conversion.




Figure 1.1 External Views of SC8SG Conductivity Detectors (example)

1.2 Specifications

1.2.1 Standard Specifications

Cable with pin terminals (applicable to FLXA202, FLXA21, FLXA402)

Cable with M3 ring terminals (applicable to FLXA402, SC450G)

Cable with M4 ring terminals (applicable to FLXA202, FLXA21)

Variopin connector (applicable to SA11)

Object of measurement: Conductivity of liquids

Measuring Principle: 2-electrode system or 4-electrode system

Cell Constants: 0.01 cm⁻¹, 0.1 cm⁻¹, 10 cm⁻¹ (for two-electrode system)
10 cm⁻¹ (for four-electrode system)

Measuring Ranges: 0-0.5 μS/cm to 0-100 μS/cm for a cell constant of 0.01 cm⁻¹
0-10 μS/cm to 0-10 mS/cm for a cell constant of 0.1 cm⁻¹
0-1 mS/cm to 0-1000 mS/cm for a cell constant of 10 cm⁻¹

Temperature Range: 0° to 100°C (130°C maximum only for 0.01 cm⁻¹ cell constant detectors, excluding those with polypropylene chambers)

Pressure: 1000 kPa max. (500 kPa maximum for detectors with polypropylene chambers)

Flow rate of Sample Solution: No particular limitation applies, although a value of less than 20 L/min. is recommended for flow-through detectors.

Note: No limitation applies to flow rate (flow velocity) as far as measurement is concerned. However, when using flow-through detectors, electrodes or the inner walls of a liquid chamber may be worn out drastically at higher flow speeds if a measured solution contains slurry. Air bubbles should not be mixed in the sample solutions to obtain correct measured values.

RTD for Temperature Compensation: Pt1000 (built into the sensor)

Construction: Direct insertion (in-situ) type or flow-through types.
Rainproof encapsulation (compatible with the JIS C0920 Japanese Industrial Standard Installation:

- Screw-in type: held by the process piping
- Flange type: held by the process piping
- Flow-through type (polypropylene chamber) : mounted on a pipe (nominal diameter of 50 mm ±2 in.)
- Flow-through type (SCS14 chamber) : held by the process piping

Process Connection: Screw-in, Flange, flow-through

Construction of Wetted Part:

- Sensor-holding base; Stainless steel (316 SS) and Fluoro rubber when using Screw-in type holder or the chamber made of stainless steel. PP and Fluoro rubber when using the chamber made of PP.
- 0.01 cm⁻¹, 0.1 cm⁻¹ cell constant, two-electrode sensor: Stainless steel (316 SS) and ethylene chloride trifluorid
- 10 cm⁻¹ cell constant, two-electrode sensor: reinforced epoxy resin and graphite

1.2.2 Model and Suffix Codes

(1) SC8SG

Model	Suffix Code	Option Code	Description		
SC8SG	Conductivity detector		
Measuring range	-R31 -R42 -R61	Low range; cell constant: 0.01 cm ⁻¹ Medium range; cell constant: 0.1 cm ⁻¹ High range; cell constant: 10 cm ⁻¹		
Electrode configuration	-T -F	2-electrode system (for both 0.01 cm ⁻¹ , 0.1 cm ⁻¹ , 10cm ⁻¹ cell constants) - for general measurements 4-electrode system (for 10 cm ⁻¹ cell constant only) - for countermeasures against polarization due to contamination (*1)		
Construction	Screw-in type	-100 -101 -102	with welding socket (*2) without welding socket(a welding socket [K9208BK] should be ordered separately) R1-1/2 material: SCS14	
	Flange type	-206 -207 -208	JIS 10 K 50 RF Flange ANSI Class 150 2 RF flange (with serration) JPI Class 150 2 RF flange	
		Flow-through type (*3)	-302 -312 -303 -313 -304 -314 -305 -315	Rc1/2 female threaded; chamber material: SCS14 Rc1/2 female threaded; chamber material: PP 1/2NPT female threaded; chamber material: SCS14 1/2NPT female threaded; chamber material: PP JIS 10K 15 RF flange; chamber material: SCS14 JIS 10K 15 FF flange; chamber material: PP ANSI Class150 1/2 RF flange with serration; chamber material: SCS14 ANSI Class150 1/2 FF flange; chamber material: PP
			Cable length	-P1 -P2 -P3 -F1 -F2 -F3 -X1 -X2 -X3 -Y1 -Y2 -Y3 -VS
	Style code		*A	Style A
	Option			/PS /SS	Stainless Steel Mounting hardware (for PP chamber) Stainless Steel Mounting hardware (for SCS14 chamber)

- *1: Electrode configuration -F cannot be selected when -R31 or -R42 is selected.
When -R61 is selected, 2-electrode system -T is normally used, however, for process where detectors are susceptible to contamination, a 4-electrode system -F should be used.
- *2: If a welding socket (K9208BK) needs to be ordered beforehand, either place a separate order or prepare one by referring to the external view later in this brochure.
- *3: No chamber is equipped with a mounting hardware. Please place an order on the SC8SG with option code /PS or /SS when you select flow-through model.
The PP chamber can have cracks or splits unless it is supported by a mounting hardware.
- *4: Used for connection to FLXA202, FLXA21.
- *5: Used for connection to FLXA402, SC450G.
- *6: Used for connection with SA11. SC8SG-R61-T (Measuring range: -R61 with Electrode configuration -T) is not selectable.

Applicable converters for SC8SG

Converter	Type of terminals		
	Pin	Ring M4	Ring M3
Converter: SC100	N.A.		
Transmitter: SC202G, SC202SJ	Yes	N.A.	Yes (*1)
Converter: SC402G (*3)	Yes	N.A.	N.A.
Converter: FLXA402, SC450G	(*2)	N.A.	Yes
Analyzer: FLXA202/FLXA21	Yes	Yes	N.A.

- *1: Applicable when option code /TB (screw terminal) specified for SC202G/SC202SJ.
- *2: Both pin and M3 ring can be used, but M3 ring are recommended.
- *3: SC402G is discontinued.

SA11 Smart Adapter can connect to Variopin connector.

(2) Spare Parts for SC8SG

Parts No.	Description
K9208BA	0.01 cm ⁻¹ cell constant, two-electrode sensor
K9208BB	0.1 cm ⁻¹ cell constant, two-electrode sensor
K9208BC	10 cm ⁻¹ cell constant, two-electrode sensor
K9208BD	10 cm ⁻¹ cell constant, four-electrode sensor
K9208BV	0.01 cm ⁻¹ cell constant, two-electrode sensor, Variopin connector
K9208BY	0.1 cm ⁻¹ cell constant, two-electrode sensor, Variopin connector
K9208BZ	10 cm ⁻¹ cell constant, four-electrode sensor, Variopin connector
K9208BK	Welding socket for screw-in model
G9303EB	O-ring

(3) WU41: Dedicated cable for SC8SG

This cable can be purchased additionally. SC8SG is supplied with cables of selected length.

Model	Suffix code	Option code	Description
WU41	Dedicated Cable for SC8SG
Cable end	-F	fork terminals
	-P	pin terminals
	-X	M4 ring terminals (*1)
	-Y	M3 ring terminals (*2)
Cable length	-05	5.5 m
	-10	10 m
	-20	20 m




*1: Used for connection to FLXA202, FLXA21.

*2: Used for connection to FLXA402, SC450G


1.2.3 Dimensions

(1) Screw-in type


Only the difference between SC8SG-R□□-100 and SC8SG-R□□-101 is whether or not having a welding socket. SC8SG-R□□-100 has a welding socket but SC8SG-R□□-101 does not.







Welding socket
Parts No: K9208BK (Material: 316SS)




Note: If you make the welding socket for screw-in type, refer to the above drawing.





(2) Flange type

SC8SG-R□□-□-20□




<Flange>		<Insertion length>								
Model and Code	Flange rating	øC	øD	t	øh	H1	H2	H3		
SC8SG - R□□ - □ - 206 - □□ *A	JIS 10K 50 RF	120	155	16	19	127	74	157		
SC8SG - R□□ - □ - 207 - □□ *A	ANSI Class150 2 RF	120.7	152.4	19.1	19.1	124	71	154		
SC8SG - R□□ - □ - 208 - □□ *A	JPI Class150 2 RF	120.6	152	19.5	20	123.5	70.5	153.5		


Note: ANSI flange with serrations

(3) Flow-through type


SC8SG-R□□-□-302,
SC8SG-R□□-□-303,
Screw connection
(Chamber Material: SCS14)



• Option: Mounting hardware (-SS)




SC8SG-R□□-□-304,
SC8SG-R□□-□-305,
Flange connection
(Chamber Material: SCS14)



Flange rating	ϕC	ϕD	ϕG	ϕh	t
JIS 10K 15 RF	70	95	52	15	12
ANSI Class150 1/2 RF (with serration)	60.5	88.9	34.9	15.7	11.2


SC8SG-R□□-□-312, SC8SG-R□□-□-313,

Screw connection (Chamber Material: PP) + Option (Mounting hardware (/PS))




SC8SG-R□□-□-314, SC8SG-R□□-□-315,

Flange connection (Chamber Material: PP) + Option (Mounting hardware (/PS))



● WU41 : Dedicated cable for SC8SG



2. Components and Their Function




Figure 2.1 Components of the SC8SG Conductivity Detector and Their Functions

F0201.ai

3. Installation, Piping and Wiring

3.1 Installation

CAUTION

When ultra-pure water flows through plastic pipe, electrostatic charge may be produced.

When the sensor is installed on this plastic pipe, the electrostatic charge goes through the sensor, and into a converter circuit

This electrostatic charge will discharge and damage electronic parts on the converter circuit.

3.1.1 Preparation for Detector Installation

Mounting the detector varies with its construction.

The Screw-in type detector is mounted directly to the detector insertion port on the process piping, while the flow-through type detector is mounted on a 2-inch pipe (O.D 60.5-mm) – or on a wall, and the measured solution flow to the detector via user-provided sampling piping. In either case, provide appropriate mounting hardware for detector. Mounting procedures are described below.

(1) Screw-in type detector

The detector electrodes are mounted on the probe inner circumference, and conductivity measurement is performed for solutions flowing through the inside (see Figure 2.1). So, when using the Screw-in type detector, you need to give due consideration to solution flow inside the probe, and give special consideration to installation location when prompt response to changes in conductivity is required.

[Installation conditions for the Screw-in type detector]

- The measured solution outlet in the detector probe is immersed in the measured solution. In addition, there should be no bubbles at the measurement point.
- In general, the tip of the detector probe should be oriented to upstream of the flow.

NOTE

A two-electrode detector with cell constant of 10 cm^{-1} can also be installed perpendicular to the solution flow. In addition, if the speed of response is not so important because conductivity value and temperature change gradually, there is no restriction on detector mounting position.




Figure 3.1 Orientation of the Detector relative to Flow of Measured Solution

- At the measurement point, the temperature and pressure of the measured solution should not exceed the limits specified (refer to Section 1.2.1, earlier in this manual)
- Detectors should be removed for maintenance (when the detector is removed, make sure that the measured solution does not flow out of the insertion port).

[Machining the detector insertion port]

Figure 3.2 shows the dimensions of the detector insertion port.




Figure 3.2 Structure of Screw-in Type Detector Mounting Section

To facilitate machining the detector insertion port, the company has prepared sockets as shown in Figure 3.3. The detector mounting section of these sockets are machined as shown in Figure 3.2.




Figure 3.3 Dimensions of Insertion Holes and Sockets

F0303.ai

(2) Flow-through detector

Mounting of flow-through type detectors depends on chamber material. In general, this type of detector is mounted vertically so that the measured solution inlet is (horizontal or) oriented downwards.

Note: The flow-through detector may also be mounted either on a slant or horizontally, but the measured solution outlet should be oriented to point upwards.

[Installation conditions for the flow-through detector]

- The installation location should be chosen so that the sampling pipe is short.

Note: If the sampling pipe is long, rapid fluctuations in the conductivity of the process solution may not be detected in the measured value.

[Detector installation requirements]

- When a stainless steel (SCS14) chamber is used:

Basically, the detector should be supported by the connecting pipes. Install the detector when the sampling pipes are installed (refer to Section 3.2).

- When a polypropylene chamber is used:

Install the detector on a pipe of nominal size 50-mm (outer diameter 60.5 mm) or on a plate. When the detector is mounted on a pipe, fasten the detector to the mounting pipe with a U-shaped bolt. Install the pipe either vertically or horizontally.

When the detector is mounted on a plate, remove the pipe mounting bracket from the detector and fix the detector to the mounting plate with two M8 screws. Drill two 9-mm dia. holes in the mounting plate as shown in Figure 3.4.




Figure 3.4 Hole Drilling for Plate Mounting

3.1.2 Detector Installation

A Screw-in type detector is attached to the socket provided on the detector insertion port (see Figure 3.2). Be sure that the O-ring is installed in the socket, and tighten the fixing nut firmly. mark sure that the measured solution outlet points to the downstream side of the measured solution flow as indicated by the arrow mark.

A flow-through type detector with polypropylene chamber material should be mounted securely on its mounting pipe in the predetermined position. A flow-through type detector with a 14 SS stainless steel chamber should be installed at the same time as sampling pipes are installed.

3.2 Piping

When using a flow-through type detector, make a sampling piping connection to flow the process solution into the detector. This section describes the procedures for sampling pipe connection. When connecting flow-through detectors directly on the process piping, follow the instruction in the section.

3.2.1 Piping Materials

When flow-through detectors are screw-connected, an Rc 1/2 or 1/2 NPT thread female connection is provided. For flange-connected detectors, when the chamber material is polypropylene the provided flange may be JIS 10K 15 FF equivalent or ANSI Class150 1/2 FF, and when the chamber material is SCS14 the provided flange may be JIS 10K 15 RF or ANSI Class150 1/2 RF with serrations.

Use the following piping materials for piping connected to the detector. Select piping joints appropriate for the piping materials used.

[For polypropylene chambers]

- Hard polyvinyl chloride pipe (JIS K 6741), nominal diameter 16 mm
- polypropylene pipe, nominal diameter 16 mm
- Wire mesh reinforced flexible PVC tube, nominal diameter 15 mm

[For stainless steel chamber]

- Stainless steel pipe (JIS G 3459)
- Stainless steel (304 SS) or Stainless steel (316 SS), nominal diameter 15 mm

3.2.2 Making Sampling piping

Make sampling piping as per the following procedures:

(1) Cautions when making piping

[Pressure of the measured solution]

When a stainless steel (SCS14) chamber is used, pressure of the measured solution can be up to 1 MPa. When a polypropylene (PP) chamber is used, pressure of the measured solution can be up to 500 kPa maximum.

Absolute maximum pressure of the measured solution also depends on the piping materials used.

[Flow of the measured solution]

There are no special restriction on flow (flow velocity) as regards measuring conductivity.

NOTE

If the temperature of the measured solution varies, and the conductivity is converted to a value at a reference temperature, the response of the temperature detector must be taken into account. Note that under normal measuring conditions, the temperature detector in the SC8SG conductivity detector has sufficiently fast response the flow velocity of the measured solution will not be an issue. However, if measured solutions containing slurry are passed through the detector and chamber at high rates of flow, the detector or chamber may be worn out by abrasion. To avoid this, you should restrict maximum flow rate to about 20 liters/min. and aim for a minimum flow rate of about 1 liter/min.

[Temperature of the measured solution]

The maximum temperature of the measured solution is restricted according to the heat resistance of the chamber and piping materials used.

NOTE

The maximum temperature for a polypropylene (PP) chamber is 80°C. For a stainless steel (SCS14) chamber, the maximum temperature of the measured solution is 100°C for detector with a cell constant of 0.01 cm⁻¹ / 0.1 cm⁻¹, or 130°C for detectors with a cell constant of 10 cm⁻¹.

When reference temperature conversion is performed, in order to improve the measurement accuracy, select temperature close to the reference temperature to minimize the effect of temperature coefficient.

[Bubbles in measured solution]

If the measured solution contains bubbles, this may cause the measured value to fluctuate.

If the measured solution contains large amounts of bubbles, or where bubbles are generated by a pressure drop, use an overflow tank as shown in Figure 3.5 to reduce the bubbles.




Figure 3.5 Piping Example where Measured Solution contains large amounts of bubbles

(2) Procedures for piping

[Position of the measured solution outlet]

When a polypropylene chamber is used, be sure that the outlet for the measured solution is correctly oriented the piping.

The measured solution outlet can be oriented either forward, to the right or left. When the detector is plate-mounted, the measure solution outlet can also be oriented backwards (see figure 3.4 for reference). To change the direction of the measured solution outlet, remove the detector together with the socket, and loosen the four bracket mounting screws as shown in Figure 3.6 to remove the solution chamber.

Note: The measured solution outlet is oriented to the right side at the factory before shipment.




Figure 3.6 Removing Bracket

Where the detector is mounted horizontally, be sure that the measured solution outlet is oriented upwards.




Figure 3.7 Piping Connection Where Detector Solution Chamber Is Positioned Horizontally

[To help avoid problems with the detector]

Use appropriate materials for piping, to avoid corrosion or damage.

- If corrosive components are contained in the measured solution, take special care in selecting sealing parts – such as gaskets, and the like – with corrosion resistance.
- If the detector is mounted on – and supported by – the piping, it is likely that force may be applied to the piping during detector maintenance. To avoid this, provide a support adjacent to the detector, and fix the piping to the support.
- If slurries are likely to accumulate in the solution chamber, provide an appropriate drain connection in the measured solution inlet.

[For safety, during maintenance]

- Provide a stop valve to prevent the measured solution from running out of the detector insertion section when the detector is removed for inspection or maintenance.

4. Operation

Check that the conductivity measuring system is operating correctly and providing appropriate measurements. Then place the system in steady operation. For converter operating instruction, refer to the separate converter User's Manual.

This chapter provides operating instructions for detectors.

4.1 Preparation for Operation

4.1.1 Checking Piping and Wiring

[Checking Wiring]

Check that detector cable connections are correct.

- Check that calibration can be performed without any problems.
- Check that the sensor cable connector is secured with the associated locknut.
- Check that the detector cable is appropriately protected from damage.
- Check that the detector cable length is appropriate.

[Piping and detector installation conditions]

- Confirm that (temperature and corrosion resistance of) piping materials is appropriate for the solution(s) to be measured.
- Check that the solution level reaches the measured solution outlet when the flow of measured solution is started.
- Check that the measured solution outlet of the detector is oriented to point to the downstream side of the piping.
- Check that the detector can be readily removed for maintenance.

4.1.2 Flowing Measured solution

Check that there are no problems in flowing the measured solution:

- Check piping connections for measured solution leaks.
- Check that pressure and temperature are within the permitted operating ranges.

4.1.3 Checking Operation

After setting the operating parameters and calibrating, run the conductivity measuring system and check that measurements are normal.

- Check whether bubbles in the measured solution are affecting measurement stability and accuracy.
- Check whether there are rapid changes in solution temperature which may affect accuracy of reference-temperature-converted conductivity measurement.

If there any problems with measurement accuracy, try slowing down the flow velocity, changing the measurement point, and also avoid mixing solutions with different temperatures.

4.2 Steady-State Operation

In steady-state operation, perform periodical calibrations using standard solutions to maintain the measurement accuracy. For details of checks and maintenance to be performed during steady-state operation, refer to the separate converter User's Manual.

Note: When the measured solution is free of contaminants, the SC8SG detector can operate without maintenance for extended periods of time (usually, one year or so).

4.2.1 If any problem arises during operation

If the converter detects any problem in the detector system, it outputs a FAIL contact signal. If any problem is found, refer to the separate converter User's Manual and promptly take corrective action.

4.2.2 Cautions When Stopping or Resuming Operation

If the detector is stored in the atmosphere for a long time after its operation has been suspended, wash off contamination from the detector.

When resuming detector operation, perform calibration using standard solutions.

5. Inspection and Maintenance

The SC8SG Conductivity Detector can be used not only for measuring general solutions (at normal temperatures and where suspended solids etc. that may contaminate the detector are low levels) but also for measuring the conductivity of solutions under bad conditions, such as high-temperature solutions or those containing corrosive or suspended solids that may adhere to and contaminate the detector.

When used to measure general solutions, this detector permits maintenance-free operation for extended periods. However, for measurement of solutions under bad conditions, periodic inspection and maintenance (e.g., detector cleaning) is required to maintain measurement accuracy. The interval for inspection and maintenance as described below should be determined according to the characteristics of the measured solutions.

5.1 Cleaning the Detector

5.1.1 Guidelines for Cleaning

Detector contamination tends to encourage electrode polarization and result in inaccurate measurements. If you find that detector contamination is affecting measurement accuracy, clean the detector. You should determine the optimum maintenance interval, so that maintenance is cost effective. Guidelines for cleaning detectors are given below:

For detectors (with cell constant of 0.01 cm^{-1}) used for measuring low conductivities up to $100 \mu\text{S/cm}$, the amount of impurities in measured solutions is not likely to be a problem. Therefore, detector cleaning is not required for intervals of a year or more.

For detectors (with cell constant of 0.1 cm^{-1}) used for measuring low conductivities up to 10 mS/cm , or two-electrode detectors with cell constant of 10 cm^{-1} for measuring conductivities up to 1000 mS/cm , you can clean the detectors at calibration time. You don't need the cleaning at short intervals.

Four-electrode detectors with cell constant of 10 cm^{-1} are unlikely to be affected by polarization. Therefore, four-electrode detectors are better for high-conductivity measurements or for measurement of solutions containing suspensions that may adhere to the detector.

Detectors used to measure solutions with high conductivity and/or suspended solids generally need more frequent detector cleaning than the low-conductivity case. In general, you may need to clean detector used to measure high conductivity solutions at a more frequent intervals than just at calibration time.

5.1.2 Removing the Detector

NOTE

When removing detector, ensure that solutions to be measured do not run out of the detector insertion port, and handle with care - especially when using solutions that may be pressurized or very hot, ensure that solutions will not spurt out when detector is removed.

When removing the Screw-in detector, use an appropriate wrench to loosen the screw that locks it in its screw socket,. Turn the fixing screw counterclockwise. During these procedures, do not remove the connected detector cables. Otherwise, the inside of the connector may get wet.

5.1.3 Cleaning

The electrodes are hidden inside the probe, so we can't access them to check them for contamination. We can assume that the electrode contamination will be similar to the condition of the outer circumference of the probe, and perform the cleaning procedure below to remove the dirt:

Do not use a hard brush to clean the inside of the probe, or the electrodes may be damaged. Use a soft cotton-tipped swab for cleaning. After completing the cleaning, rinse the detectors in water.

[General contamination]

Wash out the contamination with warm water in which neutral detergent is dissolved.

[Chemical contamination including lime, hydroxide, etc.]

Use a 5 to 10% dilute hydrochloric acid solution to remove chemical contamination.

Take special care that hydrochloric acid does not get on your body or clothes during cleaning work.

[Contamination due to organic constituents, such as oil, fat, etc.]

Use acetone for cleaning.

[Contamination due to algae, microbes, molds, etc.]

Use chlorinated solvent (bleach).



WARNING

Use of chlorinated solvent (bleach)

Do not mix hydrochloric acid with chlorinated solvents (bleach), otherwise toxic chlorine gas may be generated. (When using cleaning agents, be sure to observe the warnings on the containers, etc.)

5.2 Inspection of O-ring Sealing


In cases where pressurized solution is measured, the solution may leak if the detector O-ring seal is damaged. When removing the detector for maintenance, be sure to check that the O-ring in the socket is normal. O-ring degradation or deformation will be accelerated if solution at high temperatures (over 100°C) are measured. The O-ring should be periodically replaced regardless of whether its sealing effect appears to have deteriorated.

Basic trouble shooting:

If the converter detects an abnormality in the detector, it outputs a FAIL signal to alert the user. In this case, refer to the separate User's Manual to solve the problem.

Customer Maintenance Parts List

SC8SG Conductivity Detector



Item	Part No.	Qty	Description
1	—	1	Sensor
	K9208BA	—	0.01 cm ⁻¹ cell constant, two-electrode sensor
	K9208BB	—	0.1 cm ⁻¹ cell constant, two-electrode sensor
	K9208BC	—	10 cm ⁻¹ cell constant, two-electrode sensor
	K9208BD	—	10 cm ⁻¹ cell constant, four-electrode sensor
	K9208BV	—	0.01 cm ⁻¹ cell constant, two-electrode sensor, Variopin connector
	K9208BY	—	0.1 cm ⁻¹ cell constant, two-electrode sensor, Variopin connector
	K9208BZ	—	10 cm ⁻¹ cell constant, four-electrode sensor, Variopin connector
2	—	1	Lock nut
	K9208BP	—	For SCS14 (except for suffix code of -31□)
	K9315PB	—	For PP (for flow-through type, suffix code of -31□)
3	K9208BL	1	Washer
4	G9303EB	1	O-ring
5	K9208BK	1	Welding socket for screw-in type
6	—	1	Socket
	K9208BH	—	For SCS14 (suffix codes of -102, -20□, -30□)
	K9315PA	—	For PP (suffix code of -31□)
7	—	1	Flange
	L9840EA	—	JIS 10K50 RF (for suffix code of -206)
	L9840QA	—	ANSI Class150 2 RF (for suffix code of -207)
	L9840KA	—	JPI Class 150 2 RF (for suffix code of -208)
8	—	1	Chamber
	K9053LD	—	Material: SCS14 (for suffix code of -302)
	K9053JN	—	Material: PP (for suffix code of -312, -313)
	K9053LK	—	Material: SCS14 (for suffix code of -303)
	K9053MD	—	Material: SCS14 (for suffix code of -304)
	K9053KG	—	Material: PP (for suffix code of -314)
	K9053PB	—	Material: SCS14 (for suffix code of -305)
	K9053KN	—	Material: PP (for suffix code of -315)
9	K9115RS	2	1/2 NPT Adaptor for SC8SG - R□1-□ - 313
10	K9053JT	1	Pipe mounting hardware for /PS option
11	Y9514ZU	4	Screw
12	K9053LR	1	Mounting hardware for /SS option

Revision Information

- Title : Model SC8SG Conductivity Detector
- Manual No. : IM 12D08G02-01E

Sep. 2019/7th Edition

Added Medium range (-R42), Variopin connector (-VS) (Chapter1, p.2-1, 3-2, 3-6, 3-8, 5-2)
Revised CMPL
Reviewed overall

Nov. 2018/6th Edition

Added FLXA402
P i, P1-2, P1-4, P1-5

Oct. 2015/5th Edition

Added FLXA202
P i, P1-2, P1-4, P1-5
Unification of the material name
P1-2, P3-5.

Aug. 2015/4rd Edition

P1-4 Description of Measuring range added to "1.2.2 Model and Suffix Codes".
P2-1 The Name plate and the cell constant label added to Figure 2.1.
P3-1 Symbol Marks of "IMPORTANT" added to "3.1 Installation".

Jun. 2011/3rd Edition

Pi Manual No. of FLXA21 added.; P1-1 Some of cable label description modified.
P1-2 Some of wetted part materials modified; P1-3 M4 ring terminal of FLXA21 added to MS-code.
P1-4 FLXA21 added to combination of detector and converters; P1-5 to P1-9 Some of cable label description on dimensions modified, etc; P3-7 Some description of "Wiring" modified.

Jan. 2008/2nd Edition

Ring terminals added for SC450G converter.

June 2004/1st Edition

Newly published

■ If you want to have more information about Yokogawa products, visit our web site:
<http://www.yokogawa.com/>
